


Top right click on "Settings"

Settings

 "Ok Google" detection

General Settings


 Network & Internet
velocity office

 Accounts & Sign In
No accounts

 Apps

 Device Preferences

 Remotes & Accessories

 More Settings



Scroll down and click on "More Settings"


 Display

 HDMI CEC

 Playback settings

 Audio Output

 Powerkey definition

 Upgrade bluetoothremote

 Netflix ESN

 Picture



Scroll to "Powerkey definition" and click

Powerkey definition

sleep now

shutdown

restart



Change to "shutdown"

Droid Settings

 Display

 HDMI CEC 

 Playback settings

 Audio Output

 Powerkey definition

 Upgrade bluetoothremote

 Netflix ESN

 Picture

Back to 2nd page of settings - click on HDMI CEC button

CEC Control

CEC Switch



One key play



One key power off



Auto change language



Ensure the only button on is CEC Switch button. Click off others.